

Blades Accessories - WOOX Genuine Leather Axe Collar Axe accessory Collar / Axe AX1 Axe

Overstrike Protection: Shielding the neck of the wooden handle from mis-swings (overstrikes) and general field wear, significantly extending handle longevity.

Craftsmanship: Hand-stitched in Florence, Italy, by expert artisans using full-grain Tuscan leather.

Weather Treatment: Conditioned with natural vegetable oils and waxes for enhanced durability and weather resistance.

Fit and Attachment: Custom-contoured for the AX1 handle profile, utilizing durable cinch lacing/stretching for a tight, shift-free fit.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Genuine Leather Axe Collar Axe accessory Collar / Axe AX1 Axe
- Manufacturer: WOOX
- Product no.: EU2019292
- Mfr. No.: BU.SHT003.01
- Colour: Black
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069390970

Table of Contents

- [Startpage](#)
- [English: WOOX Blades Accessories Safety Instruction Guide](#)

WOOX Blades Accessories Safety Instruction Guide

Introduction

Thank you for choosing the WOOX Genuine Leather Axe Collar for your AX1 axe. This product is designed to provide overstrike protection and enhance the longevity of your axe handle. To ensure safe and effective use, please read this safety instruction guide carefully. It is important to follow all safety guidelines and precautions outlined in this document.

General Safety Guidelines

- Ensure that the Axe Collar is properly fitted to the AX1 handle before use to prevent slippage during operation.
- Regularly inspect the Axe Collar for any signs of wear or damage. Replace it if any defects are found.
- Keep the Axe Collar clean and free from debris to maintain optimal performance.
- Store the axe in a dry place to prevent moisture damage to the leather.
- Always supervise children and vulnerable individuals when using or handling axes and accessories.

Specific Safety Precautions for Use

- Avoid using the axe in wet or slippery conditions to reduce the risk of accidents.
- Do not use the axe for purposes other than chopping wood or similar tasks.
- Wear appropriate personal protective equipment (PPE) such as gloves, safety goggles, and sturdy footwear when using the axe.
- Ensure that bystanders are at a safe distance when swinging the axe.
- Be aware of your surroundings and avoid using the axe near people, animals, or fragile objects.

Instructions for Installation and Usage

1. Installation of the Axe Collar

- Remove any existing accessories from the AX1 handle.
- Align the Axe Collar with the neck of the handle.
- Use the durable cinch lacing to secure the collar tightly around the handle. Ensure it is shiftfree and snug.

2. Using the Axe

- Always check that the Axe Collar is securely attached before using the axe.
- Grip the axe handle firmly and swing in a controlled manner.
- If you experience any resistance or difficulty while using the axe, stop immediately and inspect the Axe Collar and handle for any issues.

3. PostUse Care

- After use, wipe the Axe Collar with a damp cloth to remove any dirt or debris.
- Allow it to air dry completely before storing.
- Store the axe in a cool, dry place, away from direct sunlight and moisture.

Disposal Instructions

- When the Axe Collar is no longer needed or has reached the end of its life, dispose of it responsibly.
- Leather products can often be recycled or composted. Check local guidelines for proper disposal methods.
- Do not burn the Axe Collar as it may release harmful substances.

Contact Information for Further Support

For any further inquiries or safety concerns, please contact your local distributor or refer to the product packaging for additional information.

By following these guidelines, you can ensure a safe and enjoyable experience with your WOOX Genuine Leather Axe Collar. Thank you for your attention to safety!