

Blades Accessories - WOOX Solo Sheath Axe accessory Sheath / Axe Solo Leather

Keep the razor-sharp edge of your WOOX Solo axe protected and carry-ready with this custom-fit black leather sheath. Tailored to match the exact profile of the Solo head, this sheath prevents accidental damage to your blade and gear while ensuring safe transport on every adventure.

Key Features

Genuine Italian Leather: Handcrafted in Italy from high-grade black leather, designed for rugged durability, long-lasting resilience, and a sleek outdoor aesthetic.

Precision Molded Fit: Custom-engineered specifically for the WOOX Solo axe blade, delivering a secure snap that stays firmly in place.

Safe Transport and Storage: Shields the cutting edge from exposure, preventing dulling during travel and protecting your hands or backpack contents.

Refined Craftsmanship: Features durable stitching and robust hardware built to handle harsh wilderness environments.

NO IMAGE
AVAILABLE

Attributes

- Name: WOOX Solo Sheath Axe accessory Sheath / Axe Solo Leather
- Manufacturer: WOOX
- Product no.: EU2019301
- Mfr. No.: BU.SHT007.01
- Colour: Black
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 810069392363

Table of Contents

- [Startpage](#)
- [English: WOOX Solo Sheath Safety Instructions](#)

WOOX Solo Sheath Safety Instructions

Introduction

Thank you for choosing the WOOX Solo Sheath Axe accessory. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your sheath. It complies with the EU General Product Safety Regulation (GPSR), ensuring your protection during use.

General Safety Guidelines

- Always inspect the sheath for any signs of damage before each use.
- Keep the sheath away from children and vulnerable individuals to prevent accidental injuries.
- Ensure that the axe is securely fitted in the sheath before transporting it.
- Store the sheath in a dry place to maintain the integrity of the leather.
- Report any unsafe products or accidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Avoid Contact with Water:** Water can damage the leather and compromise the sheath's integrity.
- **Do Not Overload:** Ensure that the sheath is only used for the WOOX Solo axe. Do not attempt to use it for other tools or equipment.
- **Handle with Care:** Always handle the sheath with clean hands to prevent dirt or oils from damaging the leather.
- **Check the Fit:** Ensure that the axe fits snugly in the sheath. If it feels loose, do not use it until the issue is resolved.
- **Transport Safely:** When carrying the sheath, ensure it is secured to prevent accidental opening and exposure of the blade.

Instructions for Installation and Usage

1. Fitting the Axe:

- Align the axe blade with the opening of the sheath.
- Gently slide the axe into the sheath until it is fully enclosed.
- Ensure the sheath snaps securely into place.

2. Removing the Axe:

- Hold the sheath firmly in one hand.
- Grip the axe handle with the other hand and gently pull it out of the sheath.
- Avoid twisting or forcing the axe out to prevent damage.

3. Transporting the Sheath:

- Always ensure the axe is securely fitted in the sheath before transport.
- Carry the sheath in a safe manner to avoid accidental openings.

4. Cleaning and Maintenance:

- Wipe the sheath with a dry cloth after each use to remove dirt and moisture.
- If necessary, use a leather conditioner to maintain the leather's quality.

Disposal Instructions

- Dispose of the sheath responsibly, ensuring that it does not pose a risk to the environment.
- If the sheath is damaged beyond repair, it should be recycled or disposed of in accordance with local regulations.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please contact the designated EUbased contact point for assistance. Ensure that you have the product details ready for a more effective response.