

CELLVAULT 21 BATTERY STORAGE FOR 21700 & SL B50 URBAN GRAY

CELLVAULT-21 BATTERY STORAGE FOR 21700 AND STREAMLIGHT SL-B50

Protect your spare 21700 battery while keeping it immediately accessible with the CellVault-21 Rechargeable Battery Storage. Premium batteries require protection from physical and environmental damage but need to remain accessible to keep advanced tactical lights running at full power. The CellVault-21 Rechargeable Battery Storage provides the same feature set as our popular CellVault-18 including dual-wall construction & side viewing windows but adds a larger capacity and an upgraded latch that allows for easy installation, especially on tight MOLLE/PALS webbing. **FEATURES:** Holds one 21700 Rechargeable Battery Holds one Streamlight SL-B50 Battery (with foam removed) Waterproof O-ring seal rated to IPX7 at 2 meters for 30+ minutes Secure metal latch seals and attaches the CellVault-21 to gear Silicone foam shock absorber/noise silencer Clear side windows allow for gear status checks Slim profile: less than 1 MOLLE/PALS column wide for easy integration into existing gear configurations Detachable latch installs easily on all MOLLE and can be backed up with the included security pin Designed and manufactured in the USA **INSTALLATION:** Unlock the bottom latch and open the CellVault-21. Press the release tab with a screwdriver or similar tool to release the latch from the back strap. Insert the back strap through the MOLLE/PALS webbing. Align the side tabs and snap the latch back into the back strap. Install additional security pin through both the latch and back strap if necessary. Verify foam shock absorber is at the bottom of the CellVault-21 tube. Insert battery with the positive (+) terminal towards the foam at the bottom. Close the latch, making sure no material is caught in the tube/cap interface.



Attributes

- Name: CELLVAULT 21 BATTERY STORAGE FOR 21700 & SL B50 URBAN GRAY
- Manufacturer: THYRM LLC
- Product no.: 430113965
- Mfr. No.: CV21005
- Delivery weight: 0.059kg
- Shipping height: 44mm
- Shipping width: 191mm
- Shipping length: 114mm
- UPC: 765855322294

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: CELLVAULT 21 Battery Storage Safety Instructions](#)

CELLVAULT 21 Battery Storage Safety Instructions

Introduction

Thank you for choosing the CELLVAULT 21 Battery Storage for your 21700 and Streamlight SLB50 batteries. This guide provides important safety information, installation instructions, and usage guidelines to ensure your product is used safely and effectively. Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure the product is used only for its intended purpose as described in this manual.
- Keep the product out of reach of children and vulnerable individuals to prevent accidents.
- Inspect the product regularly for any signs of damage. If any damage is found, discontinue use immediately.
- Do not expose the product to extreme temperatures, moisture, or direct sunlight, as this may compromise its integrity and performance.
- Use only compatible batteries (21700 rechargeable batteries and Streamlight SLB50 batteries) to avoid hazards.
- Report any unsafe products or accidents to the appropriate authorities and check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always verify that the battery is correctly oriented before closing the latch.
- Ensure that no foreign objects or materials are caught in the tube/cap interface before securing the latch.
- Do not attempt to disassemble or modify the product, as this may lead to malfunction or personal injury.
- Avoid using the product in environments where it may be exposed to excessive physical stress or environmental hazards.
- In case of battery leakage or swelling, handle with care and dispose of the battery according to local regulations.

Instructions for Installation and Usage

1. Unlocking and Opening the CellVault21:

- Unlock the bottom latch and open the CellVault21.

2. Installing the Back Strap:

- Press the release tab with a screwdriver or similar tool to release the latch from the back strap.
- Insert the back strap through the MOLLE/PALS webbing.
- Align the side tabs and snap the latch back into the back strap.
- If necessary, install the additional security pin through both the latch and back strap.

3. Inserting the Battery:

- Verify that the foam shock absorber is at the bottom of the CellVault21 tube.
- Insert the battery with the positive (+) terminal facing towards the foam at the bottom.

4. Closing the Latch:

- Close the latch securely, ensuring that no material is caught in the tube/cap interface.

Disposal Instructions

- Dispose of the product and batteries in accordance with local regulations.
- Do not dispose of batteries in household waste. Instead, use designated battery recycling facilities.
- Ensure the product is completely empty and clean before disposal.

Contact Information for Further Support

For any inquiries or concerns regarding the CELLVAULT 21 Battery Storage, please reach out to the appropriate EUbased contact point for product safety inquiries. Ensure that you have your product information and any relevant details ready for assistance.

Thank you for your attention to these safety instructions. Enjoy using your CELLVAULT 21 Battery Storage responsibly!